



Application Overview

- Identify the type of Torpedo Ladle at different Areas
- When **A**- Ladle comes in front of the Rfid Reader the Information stored in the Rfid Tag will be transferred to the PLC and the respective LED for **A** will glow & laser A will also start functioning & give indication to the operator that when & where to stop the Loco.
- Similarly when **B**- Ladle comes in front of the Rfid Reader the Information stored in the Rfid Tag will be transferred to the PLC and the respective LED for **B** will glow & laser B will start functioning & give indication to the operator that when & where to stop the Loco.
- Similarly when **C**- Ladle comes in front of the Rfid Reader the Information stored in the Rfid Tag will be transferred to the PLC and the respective LED for **C** will glow & laser C will start functioning & give indication to the operator that when & where to stop the Loco.

Peppari+Fuchs

